

# Stax

## Installation Guide



Main Material of Manufacture - Steel

**Attention** The connection of this radiator to a central heating system should be carried out by a suitably competent person who is familiar with current regulations.

## Read this guide before starting installation

### Handling Advice

Please refer to the manual handling guidelines that are supplied with this product. This gives important information about the safe lifting of these radiators to minimise risk and damage.

### Water Treatment

These products are for use on closed heating systems only; they are not suitable for installation on secondary HWS circuits.

On completion of the installation the entire system MUST be thoroughly cleaned and flushed to remove debris/flux residues etc. If a chemical cleanser is used, it must be thoroughly flushed from the system. Following this, the system MUST be dosed with a good quality water treatment to prevent corrosion. System design, flushing and dosing must be in accordance with BS 5449: 1990, BS EN 12828: 2003 and BS 7593: 1992

**IMPORTANT:** Failure to observe these requirements will render the guarantee on the product void.

Corrosion inhibitor must be used in accordance with the manufacturer's instructions and recommendations and should take into account the particular metals within the system.

### Cleaning & Aftercare

The external surface of the radiator should be cleaned with mild detergent. No solvents or abrasives should be used.

### Operating Pressure

Maximum 6 bar


### Further Information

These radiators have been designed, manufactured and tested to ensure a long-lasting use. Should you require any further information, help or advice, or have any difficulties with these products or their installation and use, please contact our office on:

Telephone: +44 (0)1323 486848 : Fax +44 (0) 1323 486687

Web: [www.radiatorcentre.com](http://www.radiatorcentre.com)

write to: 2 Grand Parade Polegate East Sussex BN26 5HG



# Installation Instructions

**The Stax radiator is designed to stand against a firm and vertically true wall. Position the radiator at the required installation location and mark off on the wall the three fixing points which are located at the underside of the lowest platform. Drill the wall and insert suitable wall fixings and firmly secure the unit to the wall.**

Install the air vent into the tapping at the top rear face of the left hand riser.

Connect the flow and return pipes via the selected radiator valves to the water connection tappings which are located at the underside of the lowest platform and fill, vent, balance and test the radiator.

