

FITTING INSTRUCTIONS


Altima Spa Towel Radiator

Tools & Material Required

Suitable valves
PTFE tape
Silicone thread sealant
Tape measure
Allen key - 13mm & 12mm (when installing Bisque valves)
Screwdriver - large flathead
Electric drill
Masonry drill bit
Spirit level
Step ladder (for taller radiators)

Key Component Qty

A Air Vent - 1/4"	1
B Boss	4
C Bolt - Square Head	4
D Wall Plug	4
E Bracket	4
F Screw, 7mm dia x 70mm 4	
G Washer	4
H Grub Screw	4
I Allen Key	1



Assembly Instructions

Sufficient PTFE tape must be applied to valve-tail threads prior to their installation.

Silicone thread sealant should be applied to all threaded components manufactured with 'O-rings'.

Fit valve tails, using correct size Allen key.

Fit air vent (A).

Attach bosses (B) to tabs on the back of the radiator by sliding square headed bolts (C) into slot in bracket and rotating boss until tight.

Accurately mark out bracket holes on wall using spirit level, to dimensions as shown on Technical Data Sheet.

Drill four holes to a minimum depth of 65mm & insert wall plugs (D).

Attach brackets (E) to wall with screws (F) & washers (G).

Hang radiator onto wall by inserting bosses (B) into brackets (E).

Tighten grub screws (H) with Allen key (I).

Plumb radiator to heating circuit with flow opposite air vent.