



- |    |  |                 |       |
|----|--|-----------------|-------|
| 1- |  | Allen Key       | 1 pcs |
| 2- |  | Bracket         | 4 pcs |
| 3- |  | Short Pilar Nut | 4 pcs |
| 4- |  | Grub Screw      | 8 pcs |
| 5- |  | Wall Plug       | 4 pcs |
| 6- |  | Screw, dia 6mm. | 4 pcs |
| 7- |  | Air Vent        | 1 pcs |
| 8- |  | Blanking Plug   | 1 pcs |

### Wall Mounting Instructions:

- 1- According to the relative wall connection axis (L) & (S) drill 4 Nr holes 10 mm.Ø x 50 mm. depth.
- 2- Insert wall plugs (5) into the drilled holes.
- 3- Screw the brackets (2) with the screws (6) into the wall plugs (5).
- 4- The Short Pilar Nuts (3) are screwed into the collectors at the back of the radiator as shown.
- 5- Offer up the radiator and insert the short pillar nuts (3) into the brackets (2).
- 6- Using the allen key (1) provided, retain the short pillar nuts (3) into the brackets (2) with the grub screws (4).



**Note :** Flow / Return can not be reserved.  
If heating element is installed, push the diverter with a screwdriver.

**Water Connections : 1/2" BSP**  
Not suitable for use with direct hot water systems. Not suitable for gravity circulation.

Product Code	Width	Height	nn. Centi	Assembly Axis		No. Of Tubes
	W	H	C	S	L	
MISS1500-05	320	1500	320	195	1420	5
MISS1800-05	320	1800	320	195	1720	5
MISS1500-07	450	1500	450	325	1420	7
MISS1800-07	450	1800	450	325	1720	7

\*All measurements are in millimetres  
The picture is used subject to alteration or without notice