

FITTING INSTRUCTIONS

Bow Fronted Towel Radiator

Tools & Material Required

Suitable valves
PTFE tape
Silicone thread sealant
Tape measure
Electric drill
Masonry drill bit - 8mm diameter
Spirit level
Stepladder (for taller radiators)
Allen key - 13mm & 12mm

Key Component Qty

A Bracket Post	4
B Spacer	4
C Air Vent - "1/8"	1
D Wall Plug	4
E Bracket	4
F Screw - 6mm dia x 50mm	4
G Washer	4
H Grub Screw	4
I Allen Key	1
J Air Vent Key	1

Assembly Instructions

Sufficient PTFE tape must be applied to valve-tail threads prior to their installation.

Silicone thread sealant should be applied to all threaded components manufactured with 'O-rings'.

Screw bracket posts (A) & spacers (B) onto studs on the rear of the radiator.

Fit valve tails, using correct size Allen key.

Fit air vent (C).

Accurately mark out bracket holes on wall using spirit level. Drill four 8mm diameter holes to a minimum depth of 65mm & insert wall plugs (D).

Screw brackets (E) into wall plugs (D) with screws (F) & washers (G).

Slide bracket post (A) on radiator into bracket (E) and secure in position by tightening grub screw (H) with allen key (I).

Plumb radiator to heating circuit with flow opposite air vent.

